




CABINET PARTS

For Models: EV150NXEN00
(Almond)

VERTICAL FREEZER



1		Cabinet (Not A Serviceable Part)
2	4357104	Top, Hinge
3	4357102	Bottom Hinge
4	4357108	Grille
5	4357139	Screw
6	4356803	Clip, Grille
7	4356805	Screw
8	4356801	Washer (3)
9	4356828	Shim Bottom
12	4357045	Leg, Leveller
13	4390489	Shim
14	4356830	Screw
15	4357122	Cover, Hinge
16	4357118	Power Cord
17	4357159	Clamp
18	4357147	Drain Hose
19	4356403	Clamp

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch-Up Material

350956	*Enamel, Almond (13 Oz. Spray Can)
350930	*Enamel, White (13 Oz. Spray Can)
72107	Brush Touch-Up Kit (Almond)
72017	Brush Touch-Up Kit (White)

*CAUTION: The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

978883	Enamel, Almond (1 Qt. Uncut)
799344	Enamel, White (1 Qt. Uncut)


LITERATURE PARTS

LIT4356948	Use & Care Guide
LIT4357176	Energy Label

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
978941	Insulation Fiberglass (63-1/2" x 35-1/2 x 2-5/8")
505587	Sealer Mastic (1 Qt.)
503695	Cork Sealer (1/4 Pound)


LINER PARTS For Models: EV150NXEN00 (Almond)



1	4357163	Gate
2	4356889	Support, Fence (R.H)
3	4356890	Support, Fence (L.H)
4	4356891	Screw (4)
5	4356988	Thermostat
6	4357040	Knob, Thermostat
7	4357124	Timer, Defrost
8	4356874	Lamp, Socket
9	4356875	Bulb
10	4356934	Light Shield
11	4357041	Thermostat, Plate
12	4357042	Screw
13	4356873	Light, Switch
14	4357153	Vent Plug
15	4357172	Shelf, Lower
16	4357171	Shelf, Upper
17	4357043	Screw
18	4356800	Tubing, Thermostat
19	4357089	Bracket, Light

DOOR PARTS


For Models: EV150NXEN00
(Almond)



1	4357173	Exterior Door (Includes Insulation)
2	4357174	Interior Panel
3	4357107	Door Gasket
4	4356810	Screw
5	4356813	Trim Shelf
6	4357145	Lock, Body
7	4356842	Spring, Clip Mounting
8	4356841	Lock, Bolt
9	4356843	Screw, Lock Bolt
10	4356840	Key
11	4357144	Handle Kit (Includes Items 13, 14, 16 & 17)
12	4356812	Screw Anchor
13	4390510	Screw
14	4390511	Screw
15	4356940	Nameplate
16	4356895	Handle
17	4390553	Insert, Handle
18	4356811	Bushing, Hinge
19	4356894	Vent Plug
20	4356992	Washer

UNIT PARTS

For Models: EV150NXEN00
(Almond)



1	4357117	Cover, Evaporator
2	4357027	Evaporator
3	4357004	Fan Motor
4	4356920	Fan Blade
5	4356923	Heater Defrost
6	4356924	Shield Heater
7	4356925	Drain Pan
8	4356927	Gasket, Cover Evaporator
9	4356928	Bi-Metal Defrost
10	4356941	Clip
11	4357129	Bracket, Motor
12	4356943	Screw, Motor
13	4357110	Screw (4)
14	4357162	Compressor (Includes Items 15, 16 & 19)
15	4357156	Relay
16	4356332	Drier
19	4357157	Overload
20	4356846	Sleeve
21	4356335	Compressor, Grommet
22	4356847	Washer
23	4357054	Screw, Compressor
25	4357175	Heat, Exchanger
26	4357109	Compressor Pan
27	4356952	Thermostat, Clip
28	4357158	Condenser
29	4356970	Screw
30	4356820	Screw
31	4357154	Capacitor
32	4357020	Grommet
33	4357123	Plate, Evaporator Mount
34	4357125	Bracket
35	4356810	Screw
36	4357127	Screw
37	4357128	Shield, Motor

REFRIGERANT CHARGE 7.9 oz. (R-134A)